


ENCLOSURE ASSEMBLY  
UNIVERSAL TYPE

#6 HEX NUT (2X)

HEATER

#6 SPACER (2X)

#18 AWG



PS-3B  
TRANSFORMER

NOTE: This transformer shall be  
installed outside the enclosure.

120VAC 60Hz

REV. 1

SECUTRON INC.

TITLE: MR-2300-TH HEATER INSTALLATION INSTRUCTION		
USED ON:	MODEL MR-2300-TH	PART NO.:
DRAWN: R.Enero 12/JUNE94	APPROVED:	LT-474SEC


ENCLOSURE ASSEMBLY  
UNIVERSAL TYPE

#6 HEX NUT (2X)

HEATER

#6 SPACER (2X)

#18 AWG



PS-3B  
TRANSFORMER

NOTE: This transformer shall be  
installed outside the enclosure.

120VAC 60Hz

REV. 1

SECUTRON INC.

TITLE: MR-2300-TH HEATER INSTALLATION INSTRUCTION		
USED ON:	MODEL MR-2300-TH	PART NO.:
DRAWN: R.Enero 12/JUNE94	APPROVED:	LT-474SEC